

Repafiller Exterior

Properties

Waterproof filler with cement.

- Easy to mix
- Waterproof
- Long pot life



Use

For exterior use to fill cracks, holes and similar on mineral substrate.

Can be used indoors, where there is need for an especially strong, waterproof filler for mineral substrates, such as in wet rooms.

Substrate

Must be clean, dry, firm and suitable for surface treatment.

Treatment

Remove loose material and paint by cleaning, sanding and dusting.

Remove dirt, grime, grease and chalking materials by cleaning with Fluren 37.

Water-soluble discolouration, nicotine and soot can be cleaned with Fluren 49.

Sand flat hard, slippery surfaces.

Dampen or pre-water absorbing substrate before treatment with Filler Ude.

The filler is lightly corrosive.

Sand the surface and prime it before any additional treatment.

Application

Apply and smooth out using a filler knife.

Decide your choice of tools based on the size of the surface.

Mix while stirring - 3 parts Filler Ude with 1 part water to a uniform consistency.

Must be left for 15 min before use.

Apply a sufficient amount and then work and smooth out the filler paste.

Cold/ heat can affect the viscosity of the material.

Condensation must not occur.

Cold and increased humidity extends drying time, full curing and recoat interval

Increased temperature and low atmospheric humidity reduce drying time and full curing

Always perform a test treatment for a check and acceptance of adhesion and result

Expected result

Smooth out surface for additional treatment.

Environmental information

Remove as much filler as possible before cleaning with water. Bring remains of fluent paint to the local recycling centre.

Minimize your paint waste by pre-estimating how much paint you need. Keep the leftover paint for future use so you can effectively reduce the environmental impact.

Storage: Cool, frost-free, and tightly closed

Technical Data

Product Type	Plaster & Sealant
Density (kgs/l)	2.95
Mixture proportion	8.9 kg to 1 litre of water
m/l, depending on joint width and depth	1
Min. working temp. during application and drying/curing	Min. +10°C
Humidity	Max. humidity 80 % RH.
Drying time at 20° C, 60 % RH (Hours)	24
Recoatable at 20° C, 60 % RH (Hours)	72
Fully cured at 20° C, 60 % RH (Days)	3
Layer thickness (nominal mm)	30
Pot life (Hours)	4
Dilution	Water
Cleaning of Tools etc.	Water

Current TDS Version

August 2022

Replaces TDS Version

December 2021